

# INSTALLATION AND OPERATING INSTRUCTIONS

## CEILING/WALL VENTILATION FAN

### READ AND SAVE THESE INSTRUCTIONS

#### GENERAL SAFETY INFORMATION

1. Make sure that the electric service supply voltage is DC 12V 1A.
2. Follow all local electrical and safety codes, as well as the Nation Electrical Code (NEC) and the Occupation Safety and Healthy Act (OSH Act).
3. Always disconnect the power source before working on or near the ventilating fan, motor or junction box.
4. Protect the power cord from sharp edges, oil, grease, hot surfaces, chemicals or other objects.
5. Do not kink the power cord.
6. Do not install the unit where ducts are configured as shown in Fig. A.
7. Provide suction parts with proper ventilation.
8. This unit is UL listed for use over a bathtub or shower when installed in a GFCI protected branch circuit.




Fig. A

#### CAUTION

1. For General Ventilating Use Only. Do Not Use To Exhaust Hazardous Or Explosive Materials And Vapors.
2. Not for use in cooking areas. (Fig. B)
3. This product must properly connect to the grounding conductor of the supply circuit.
4. To reduce the risk of injury to persons, install the fan at least 8.2 feet (2.5m) above the floor.




Fig. B


#### WARNING

##### TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS, OBSERVE THE FOLLOWING:

1. Use this unit only in the manner intended by the manufacturer. If you have questions, contact the manufacturer.
2. Before servicing or cleaning unit, switch power off at service panel and lock the service disconnecting means to prevent power from being switched on accidentally. When the service disconnecting means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.
3. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
4. Sufficient air is needed for proper combustion and exhausting of gases through the flue (chimney) of fuel burning equipment to prevent back drafting. Follow the heating equipment manufacturer's guideline and safety standards such as those published by the National Fire Protection Association (NFPA), and the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE), and the local code authorities.
5. When cutting or drilling into wall or ceiling, do not damage electrical wiring and other hidden utilities.
6. Ducted fans must always be vented to the outdoors.
7. If this unit is to be installed over a tub or shower, it must be marked as appropriate for the application and be connected to a GFCI (Ground Fault Circuit Interrupter) -- protected branch circuit.
8. NEVER place a switch where it can be reached from a tub or shower.
9. Not to be installed in a ceiling thermally insulated to a value greater than R50. (This is required for installation in Canada only).

#### SUPPLIED ACCESSORIES


Part name	Appearance	Quantity
Grille		1
Fan		1
Housing		1
Duct Connector (4')		1
Tapping Screw (Ø4x25)		8
Machine Screw (#8-32x5/16'')		4



Hanger Bar		4
------------	--	---


#### 1. INSTALLATIONS

Proper insulation around the fan to minimize building heat loss and gain. 4" circular duct is recommended for installation. The ducting from this fan to the outside of the building has a strong effect on the air flow, noise and energy use of the fan. Use the shortest, straightest duct routing possible for best performance, and avoid installing the fan with smaller ducts than recommended. Insulation around the ducts can reduce energy loss and inhibit mold growth. Fans installed with existing ducts may not achieve their rated air flow.




#### MOUNT HOUSING WITH FLANGE (CEILING/ WALL)

- 1-1. To bend the housing tabs out to 90 degree and make housing tabs contact the bottom or front of the joist.




- 1-2. The housing mounts with 4 screws (Ø4x25). Screw housing to joist through lowest holes in each mounting flange, then through the other holes.



### USING HANGER BAR

1-3. Sliding hanger bars available to allow for your specific positioning of housing anywhere between joists and span up to 24".


1-4. Insert hanger bars into the channels on housing. Make sure tabs face "up" shown.



1-5. Extend hanger bars to the width of the joists. Hold fan in place with the hanger bars tabs wrapping around the bottom of joist.

1-6. Fasten hanger bars to joists with nails or screws through holes near nails.


1-7. Secure hanger bars together with screws.



### 2. DUCT CONNECTION

2-1. Insert the duct into the duct connector and tape all ductworks connection to make them secure and air tight.

2-2. Install the duct with a gradient 1°-2° to the outside.




### 3. CONNECT WIRING

3-1. Follow all local electrical and safety codes, ANSI/NFPA70.

3-2. NEVER place a switch where it can be reached from a tub or shower.

3-3. Connect wires as shown in wiring diagrams below and at the bottom right.




48v System

3-5. 18AWG is the smallest conductor that shall be used for branch-circuit wiring.

### 4. TEST RUN & GRILLE ATTACHMENT

4-1. When the power on, check for abnormal vibration or sound.

4-2. Insert the mounting springs into the slots and mount the grille to the fan unit.



### 5. OPERATION

5-1. Turn on the power switch to operate ON or OFF, and LED indicator is green.

### 6. MAINTENANCE

#### WARNING:

Disconnect power source before working on unit. Routine maintenance must be done every year.


#### CAUTION:

1. Never use gasoline, benzene, thinner or any other such chemicals for cleaning the ventilating fan.
2. Do not allow water to enter motor.
3. Do not soak resin parts in water over 140° F (60° C).

#### CLEANING :

1. Pull down the spring to remove grille.
2. Wash and clean grille. (Use non-abrasive kitchen detergent, wipe dry with new cloth.)
3. Using a cloth dampened with non-abrasive kitchen detergent, remove dust and dirt from ventilating fan. Wipe dry with new cloth.
4. Replace grille.

### DIMENSIONS




### SPECIFICATIONS

Model No.	Voltage (V)	Frequency (Hz)	Power @ 0.1SP (W)	Air Flow @ 0.1SP (CFM)	Weight (lb.)
ATX FAN 100-12v	12	N/A	10	100	5.6

Note: Design and specifications subject to change without notice.

### Simple Switch



12v System